

CS6.0

COMMERCIAL TREADMILL



PREMIUM PRESENCE

The TRUE® CS treadmills are the most powerful, ruggedly built and sophisticated machines to ever bear the TRUE name. Precision hand-built craftsmanship, innovative user-centric features and quality components vividly demonstrate our 26-year commitment to making the finest treadmills in the world. The CS6.0 was designed for those who expect more from a treadmill. A variety of programming options, heart rate training, a custom LCD display, and even integrated personal fans all result in an exceptional workout experience.

THE BEAUTY IS A BEAST

The TRUE CS6.0 is built on an 11-gauge, robotically welded steel frame that provides uncompromising stability even under the most rigorous pounding.

POWERFUL DRIVE SYSTEM

The TRUE CS6.0 comes equipped with an industry leading 5 hp MaxDrive™ AC motor that drives the largest running surface in the industry. The internal self-cooling system ensures years of powerful and dependable operation.

TRUE IMPACT ABSORPTION

TRUE's patented Soft System® offers the most biomechanically correct running surface available. Neoprene shock absorbers in the front third of the deck cushion each foot strike while the back of the deck provides a firmer surface, allowing for a stronger push off with each step.

HRC (HEART RATE CONTROL)®

The CS6.0 is equipped with a digital contact heart rate monitoring system as well as a Polar® wireless telemetry system to assist users in maintaining their optimum heart rate and maximizing workout results. HRC Cruise Control™ is also included, which allows the user to "lock in" on a specific target heart rate. Once the target is set, TRUE HRC Cruise Control will adjust speed and incline automatically throughout the duration of the workout to maintain the targeted heart rate (operates just like the Cruise Control in your car).

ENTERTAINMENT

The CS6.0 provides CSAFE power as well as seamless integration with all TRUE Entertainment™ options.

USER FRIENDLY INTERACTION

The CS6.0 console is designed to accommodate the more experienced user who utilizes programming as a means of achieving his/her fitness goals. It comes fully equipped with 19 workout programs, three of which can be custom built by the user, and five industry accepted fitness tests.

BUILT FOR THE LONG RUN

The solid steel frame is guaranteed for life. The MaxDrive motor is covered for five years, all other parts for three years. All labor costs carry a full one year warranty from the date of purchase with an optional, incremental two year plan available.

CS6.0

COMMERCIAL TREADMILL

DRIVE SYSTEM	Motor	5 hp Self Cooling, Continuous Duty MaxDrive AC Motor
	Speed Sensor	Magnetic Hall-Effect Sensor
	Power Source	120 Volt/20 Amp Dedicated (NEMA 5-20 Receptacle) Cord Length: 12' (3.7 m)
RUNNING SURFACE	Deck	Double Sided Thermally Fused Laminated 1" Medium Density Fiberboard
	Belt	Siegling™ Multi-Ply Belt with PVC Coating
	Rollers	3.5" Diameter Rollers with Sealed Bearings
	Impact System	TRUE Soft System (6 neoprene shock absorbers)
	Lubrication	Silax™ (Proprietary Lubricant)
FRAME AND LIFT	Frame	11-Gauge Heavy-Duty Welded Steel
	Pedestals	Hydroformed Steel
	Finish	Powder Coat
	Incline Motor	Compression Elevation Motor with 1000 lbs of Thrust
	Handrails	Molded Urethane, Moisture Resistant Flared Handrails
	Portability	Front Mounted Wheels with Built In Rear Handholds
	CONSOLE	Display Type
	Keys	Main Keypad: Membrane Switches; Balance Bar: Membrane Switches
	Express Command Keys	11 - Calorie Burner, Hill Intervals, Speed Intervals, Speed Ramp-Up, Glute Buster, Leg Shaper, Cardio Challenge, Sports Training, Quick Speed, Cool Down, HRC Cruise Control
	Data Readouts	Speed, Incline, Elapsed Time, Distance, Pace, Heart Rate, Time Remaining, METs, Calories, Target Heart Rate
	Message Center	17 Character Alphanumeric
HEART RATE	Contact Heart Rate	Digital - 4 Sensing Pads
	Telemetry Heart Rate	Wireless - Polar® Equipped
	HRC® Programs	1 - Target HRC
WORKOUT PROGRAMS	Preset	10 - Manual, Quick Start, Calorie Burner, Hill Intervals, Speed Intervals, Speed Ramp-Up, Glute Buster, Leg Shaper, Cardio Challenge, Sports Training
	User Defined	3 - Custom Programs
	Fitness Tests	5 - Gerkin Protocol, Military Fitness Tests (Army, Navy, Airforce, Marines)
OTHER FEATURES	Entertainment	Seamless Integration with TRUE Entertainment Options
	Communications	Full CSAFE Compatibility
	Diagnostics	Software Version, Hours, Miles, Starts, Display, Heart Rate, Backlight, Contrast, Lower Control Board, RS232, Auxiliary Boards, Remote Keys, Current, Safety Switch, Program Usage, Watch Dog
	Accessories	Reading Rack, 2 Cooling Fans, 2 Water Bottle Holders, 2 Accessory Trays
	Safety	Safety Clip Equipped
PHYSICAL SPECIFICATIONS	Footprint	84.5"L x 37"W (215 cm x 94 cm)
	Running Surface	23"W x 63"L (58 cm x 160 cm)
	Weight / Shipping Weight	520 lbs (236 kg) / 619 lbs (281 kg)
	Maximum User Weight	500 lbs (227 kg)
	Incline	0 to 18%
	Speed	0 - 12 mph (0 - 20 kph)
	Step-Up Height	11.5" (29.2 cm)
	Regulatory Approvals	UL, CSA, FCC, CE
WARRANTY	Warranty	Frame Lifetime, Motor 5 Years, Parts 3 Years, Labor 1 Year

*Specifications subject to change without notice

