

**FORM+FUNCTION**

TRUE PS900 Series light commercial bikes are available as a walk-through recumbent and traditional upright. They are perfectly suited for hotel and condominium gyms, corporate workout facilities and other vertical market applications where usage ranges from 4-6 hours per day. The PS900 bikes are comfortable, whisper-quiet and virtually maintenance free.

SELF-POWERED

The PS900 bikes are self-generating so they can be placed anywhere in your facility. The 2 stage drive system with Poly-V belts combine for a very smooth and quiet riding experience.

SEE THE DIFFERENCE

TRUE uses logical control panels and a 16 character custom LED screen that is easy to read and understand, so your users can “get on and get going” with their workout.

ADJUSTABLE, RECLINING SEAT

The TRUE PS900 recumbent bike features a multi-setting adjustable seat that optimizes range of motion, while minimizing pressure on soft tissues. The seat back reclines from 45 to 75 degrees and has 24 seat position options to enhance lumbar support.



The PS900 upright bike features a comfortable, padded seat with 15 height settings that can be adjusted to correctly fit users of all heights. Aero bars provide added comfort and leverage for long distance workouts.

TRUE HRC (HEART RATE CONTROL)®

The PS900 bikes are equipped with a contact heart rate monitoring system as well as a wireless telemetry system.

BUILT TO LAST

TRUE offers one of the most comprehensive warranties in the industry: a lifetime frame warranty, three years on parts and one year labor.



DRIVE SYSTEM	Resistance	Hybrid Self-Generating Brake
	Drive	2 Stage Drive System with Poly-V Belts
	Crank	One Piece Forged Steel Crank System With Sealed Bearings
	Power Source	Self-Generating
FRAME	Frame	Robotically Welded Heavy-Duty Tubular Steel
	Finish	Powder Coat
	Seat - RECUMBENT	Ergonomic Seat With 24 Custom Settings and Multiple Seat Back Angles
	Seat - UPRIGHT	Ergonomic Seat With 15 Position Settings
	Handlebars - RECUMBENT	Sweat-Resistant Overmolded Steel Balance Bar and Seat Handle Bar
	Handlebars - UPRIGHT	Sweat-Resistant Overmolded Steel with Integrated Elbow Support Pads
	Pedals	Integrated Adjustable Strap
CONSOLE	Display Type	LED
	Keys	Membrane Switches
	Express Command Keys	6 - Manual, Random, Cardio, HRC Cruise Control™, Fat Burn, Hills
	Data Readouts	Time, Work Level, Distance, Watts, RPM, METs, Heart Rate, Calories
	Message Center	16 Character Alphanumeric
HEART RATE	Contact Heart Rate	4 Sensing Pads
	Telemetry Heart Rate	Wireless
	HRC® Programs	1 - Time Based
WORKOUT PROGRAMS	Preset	6 - Manual, Quick Start, Random, Cardio, Fat Burn, Hills
	User Defined	N/A
	Fitness Tests	N/A
OTHER FEATURES	Entertainment	CSAFE Power Ready
	Communications	N/A
	Diagnostics	Display, Speed Sensor, Keys, Heart Rate, D/A Channel
	Accessories	Reading Rack, CD & Bottle Holder
	Safety	Reinforced Steel Frame with Secure Footprint
PHYSICAL SPECIFICATIONS	Footprint - RECUMBENT	65"L x 25"W (166 cm x 64 cm)
	Footprint - UPRIGHT	43"L x 25"W (109 cm x 64 cm)
	Weight / Shipping Weight - RECUMBENT	186 lbs (85 kg) / 210 lbs (96 kg)
	Weight / Shipping Weight - UPRIGHT	120 lbs (54 kg) / 142 lbs (64 kg)
	Maximum User Weight	350 lbs (158 kg)
	Resistance Levels	10 Watt Increments
	Resistance Range	35-400 Watts
	Maximum Workout Time	99 Minutes
Regulatory Approvals	UL, CSA	
WARRANTY	Warranty	Frame Lifetime, Brake 3 Years, Parts 5 Years, Labor 1 Year

*Specifications subject to change without notice